Roustabout-Ready™

Pump Control Panel

The Roustabout Ready™ pump control panel from Industrial Controls Solutions is a NEMA rated combination starter designed with a deep knowledge of today's technologies and practical experience of the oil and gas industries.

The Roustabout Ready™ comes standard with practical features such as prewired in/out terminal blocks for field wiring, a factory installed surge arrester, and a "PLUG AND PLAY BLOCK" for adding additional pre-wired, pre-configured optional components to save the installer time and money by eliminating any possible wiring errors.

Simple options such as a stop button or condition indicator lights install in seconds, because they all come pre-wired and preconfigured and ready to plug into the "PLUG AND PLAY BLOCK."

More advanced options such as:

- Advanced Time Clock, which keeps track of your run time, number of operations, and gives you precise pump-off times, down the minute.
- Advanced Overload Relay, which not only gives you superior phase loss and phase-unbalance protection, it can shut down quickly under a jam or stall condition.
- The Remote iKnow™ Cellular Input/Output system, which uses cellular telemetry to enable/disable devices, monitor run time, and log maintenance hours.

Also come pre-wired and pre-configured and ready to plug directly into the "PLUG AND PLAY BLOCK."


All of this makes the Roustabout Ready™ the most easily installed, easily maintained, and easiest to use pump control panels in the market today or for customers who want a more basic build it yourself pump panel package we offer our Roustabout Basic.



- Feature Rich Modified Pump Controller
- Incoming and Outgoing Terminal Blocks
- Built in lighting arrestor
- Optional
 - Advanced Time Clock
 - Remote Cellular Telemetry
 - Advance Overload Relay



Technical Specifications



Options	Code
Surge Arrestor*	SA
Plug and Play Block*	PPB
Start Button**	STA
Stop Button	STP
Hand-Off-Auto**	НОА
Remote Start/Stop	RSS
Green Light - Off	GP
Red Light - Run	RP
Amber Light - Fault	AP
Contol Power Transformer	į.
Size 1 & 2	XF12
Size 3 & 4	XF34
Size 5	XF5
Advanced Overload Relay	AOR
Standard Time Clock	SC
Advanced Time Clock	AC

^{*} Standard Feature on Roustabout Ready



1005 Metropolitan Ave. • Oklahoma City, OK 73108 • 405-601-0625 • www.OKICS.com

^{**} Standard Feature on both Roustabout Basic and Roustabout Ready